# **Dymola** Dynamic Modeling Laboratory

# Dymola Release Notes

Dymola 2023

The information in this document is subject to change without notice.

Document version: 1

© Copyright 1992-2022 by Dassault Systèmes AB. All rights reserved. Dymola® is a registered trademark of Dassault Systèmes AB. Modelica® is a registered trademark of the Modelica Association.

Other product or brand names are trademarks or registered trademarks of their respective holders.

Dassault Systèmes AB Ideon Gateway Scheelevägen 27 – Floor 9 SE-223 63 Lund Sweden

Support:https://www.3ds.com/supportURL:https://www.dymola.com/Phone:+46 46 270 67 00

# Contents

1	Impor	rtant notes on Dymola	5
2		t this booklet	
3		la 2023	
-	·	oduction	
	3.1.1	Additions and improvements in Dymola	
	3.1.2	New and updated libraries	
		veloping a model	
	3.2.1	Improved search of records	
	3.2.2	Model metadata support	
	3.2.3	Support of Markdown for documentation	
	3.2.4	Minor improvements	
	3.3 Sim	ulating a model	
	3.3.1	Better presentation of timers	
	3.3.2	Steady state solver interface	
	3.3.3	Max run time per simulation	
	3.3.4	Scripting	
	3.3.5	Minor improvements	
	3.4 Inst	allation	
	3.4.1	Installation on Windows	
	3.4.2	Installation on Linux	
	3.4.3	Dymola license server on Windows and Linux	40
	3.5 Mo	del Experimentation	41
	3.5.1	Improvements for sweeping parameters	41
	3.6 Oth	er Simulation Environments	
	3.6.1	Dymola – Matlab interface	
	3.6.2	Real-time simulation	
	3.6.3	Dymosim DLL	
	3.6.4	SSP support	
	3.6.5	FMI Support in Dymola	
	3.6.6	eFMI Support in Dymola	
	3.7 Vis	ualize 3D	
	3.7.1	Surface plots	
		delica Standard Library and Modelica Language Specification	
	3.9 Doc	cumentation	

3.10	Appendix - Installation: Hardware and Software Requirements	50
	Hardware requirements/recommendations	
3.10.2	Software requirements	50

# **1** Important notes on Dymola

#### **Installation on Windows**

To translate models on Windows, you must also install a supported compiler. The compiler is not distributed with Dymola. Note that administrator privileges are required for installation. Three types of compilers are supported on Windows in Dymola 2023:

#### Microsoft Visual Studio C++

This is the recommended compiler for professional users. Both free and full compiler versions are supported. Refer to section "Compilers" on page 50 for more information. **Notes**:

- From Dymola 2020x, Visual Studio C++ compilers older than version 2012 are no longer supported.
- From Dymola 2022x, Visual Studio 2013 is not supported anymore, due to the logistics of supporting multiple old versions for all solvers. (Visual Studio 2012 is however still supported, due to the logistics of changing the oldest supported version.)

#### Intel

**Important.** The support for Intel compilers is discontinued from the previous Dymola 2022 release.

#### MinGW GCC

Dymola 2023 has limited support for the MinGW GCC compiler, 32-bit and 64-bit. For more information about MinGW GCC, see section "Compilers" on page 50, the section about MinGW GCC compiler.

#### WSL GCC (Linux cross-compiler)

Dymola 2023 has limited support for the WSL (Windows Subsystem for Linux) GCC compiler, 64-bit. For more information about WLS GCC, see section "Compilers" on page 50, the section about WSL GCC compiler.

#### **Installation on Linux**

To translate models, Linux relies on a GCC compiler, which is usually part of the Linux distribution. Refer to section "Supported Linux versions and compilers" on page 53 for more information.

# About this booklet

This booklet covers Dymola 2023. The disposition is similar to the one in Dymola User Manuals; the same main headings are being used (except for, e.g., Libraries and Documentation).

# 3 Dymola 2023

# **3.1** Introduction

### **3.1.1 Additions and improvements in Dymola**

A number of improvements and additions have been implemented in Dymola 2023. In particular, Dymola 2023 provides:

- Better presentation of timers (page 18):
  - o Timer information in a new tab in Simulation Analysis dialog
  - Printing timer values to a text file
  - Simulation setup options for timers
- Improved search of records (page 9)
- Model metadata support (page 13)
- Support of Markdown for documentation (page 14).
- Steady state solver interface:
  - Specifying a start time for the start of dynamic steady-state finding (page 21)
  - Strict steady-state detection tolerance for dynamic steady-state finding (page 21)
- Max run time per simulation (page 24)
- Nonlinear solver statistics available for plotting (page 26)
- eFMI support in Dymola (page 48)
- Support of System Structure and Parameterization (SSP) export (page 45)
- Improved display unit handling when sweeping parameters (page 41)
- License server improvements (page 40):
  - o FLEXnet Publisher version update (Windows and Linux)
  - o 64-bit license server now also on Windows
  - o lmadmin removed
- New white paper "Using Windows Subsystem for Linux with Dymola" (page 49)

### 3.1.2 New and updated libraries

#### **New libraries**

There are no new libraries in this Dymola version.

#### **Updated libraries**

The following libraries have been updated:

- Aviation Systems Library, version 1.3.0
- Battery Library, version 2.4.0
- Brushless DC Drives Library, version 1.2.0
- ClaRa DCS Library, version 1.6.0
- ClaRa Grid Library, version 1.6.0
- ClaRa Plus Library, version 1.6.0
- Claytex Library, version 2022.1
- Claytex Fluid Library, version 2022.1
- Cooling Library, version 1.4.4
- Dassault Systemes Library, version 1.8.0
- Design, version 1.1.3
- Dymola Commands Library, version 1.13
- Dymola Models Library, version 1.5.0
- Electric Power Systems Library, version 1.6.0
- Electrified Powertrains Library (ETPL), version 1.5.0
- Fluid Dynamics Library, version 2.13.0
- Fluid Power Library, version 2022.1
- FTire Interface Library, version 1.1.3
- Human Comfort Library, version 2.13.0
- HVAC (Heating, Ventilation, and Air Conditioning) Library, version 2.13.0
- Hydrogen Library, version 1.3.6
- Model Management Library, version 1.3.1
- Multiflash Media Library, version 1.1.0
- Plot 3D Library, version 1.1.2
- Pneumatic Systems Library, version 1.5.0
- PowerTrain Library, version 2.7.0
- Testing Library, version 1.5.0
- Thermal Systems Library, version 1.9.0
- Thermal Systems Mobile AC Library, version 1.9.0
- Vehicle Interfaces Library, version 2.0.1
- VeSyMA (Vehicle Systems Modeling and Analysis) Library, version 2022.1
- VeSyMA Engines Library, version 2022.1
- VeSyMA Powertrain Library, version 2022.1
- VeSyMA Suspensions Library, version 2022.1
- VeSyMA2ETPL Library, version 2022.1
- Visa2Base, version 1.12

- Visa2Paper, version 1.12
- Visa2Steam, version 1.12

For more information about the updated libraries, please see the Release Notes section in the documentation for each library, respectively.

# **3.2** Developing a model

### 3.2.1 Improved search of records

In Dymola 2023, you can search records using a new GUI. As an example do the following:

- Open Modelica.Thermal.FluidHeatFlow.Examples.SimpleCooling, and create an editable copy of it (by right-clicking it in the package browser and selecting New > Duplicate Class..., and finally clicking OK to confirm).
- Right-click the background and select **Parameters**.
- Right-click the Medium parameter value and select Select Record....

The following dialog appears:

Select Record					?	×
Select record for me Cooling medium	edium					
						~
Search available rec - Operators <, <=, - Otherwise a partia	, =, !=, >= or > fo	llowed by numeric v	value.			
rho	ср	cv	lambda	n	u	
					Sea	arch
Name of record						
			 ۲	OK	Ca	ncel

To enter your search criteria's, double-click the criteria boxes and enter values, using the specified operators ("!=" means "not equal to"). If texts are searched for, a partial text match is done, that is, as an example, the string "dym" matches "Dymola". All specified criteria must match (logical and).

A search example, with **Search** clicked afterwards:

Select Record ? X									
Select record for medium Cooling medium									
									$\sim$
Search available rec - Operators <, <=, - Otherwise a partia	=, !=, >= or > fo	blowed by numeri							
rho	ср	cv		lambd	а		nu	I	
<1000		>=800							
						·	[	Searc	h
Name of record			rho	ср	cv	lambda	nu		
Medium: properties	of water at 10 de	gC and 1 bar	999.7	4192	4192	0.588	1.30	7E-6	
	of water at 30 de	-	995.6	4177	4177	0.615	0.8E	-6	
	s of water at 90 de	-	965.3			0.676	0.34		_
Medium: properties	Medium: properties of mineral oil at 60 degC and 1 bar 868 2010 2010 0.14 81.8E-6								
						ОК		Cance	el

You can now select the wanted record and click OK (or double-click the wanted record) to select the record in the Parameter dialog. Assume that you select the last record; the result will be:

SimpleCoo	ling	? ×
General	Add modifiers Attributes	
Component		Icon
Name		
Comment		
Model —		
Path	SimpleCooling	
Comment	Simple cooling circuit	
Parameters		
medium [	Modelica. Thermal. FluidHeatFlow. Media. Medium ()() 🗸 💷 🕨 🛛 Co	oling medium
TAmb	Modelica. Thermal. FluidHeat	Flow.Media.MineralOil()
		ancel Info

If you click the button after the medium value field, you can see the medium properties:

eneral Add m	nodifiers Attribu	tes	
Component			Icon
Name			
Comment			
1odel			
	eCooling		
Comment Simple			
	Cooling of Calc		
arameters			
medium	Modelica.	Thermal.FluidHeatFlow.Media.Medium()() 🗸 🖳	Cooling medium
TAmb		MineralOil medium	? ×
		Minute 101	
		MineralOil	
		Description	
		Medium: properties of mineral oil at 60 degC and 1 bar	
		Inputs	
		rho 868 kg/m3 Density	
		cp 2010 J/(kg.K) Specific heat capacity a	t constant pressure
		cv 2010 • J/(kg.K) Specific heat capacity a	t constant volume
		lambda 0.14 • W/(m.K) Thermal conductivity	
		nu 81.8E-6 m2/s Kinematic viscosity	
	-	OK Info Cr	eate Close

## 3.2.2 Model metadata support

Model metadata, in the form of key/value pairs, can be stored in models. The metadata is stored as an annotation in the model, and is automatically displayed in the documentation layer, if present.



There is a new dialog for viewing and editing model metadata. You can access the dialog by the command **Documentation > Meta Data** (highlighted button in previous image). The dialog is also seen in the image above.

Keys and descriptions are arbitrary text strings. Key that ends with \* is regarded as mandatory (in the example above, Author\*). A warning is shown if the corresponding description field is empty. Keys that ends with = is creating a header (for such key you cannot add any description).

If the model is read-only, the metadata is displayed, but the **OK** and **Cancel** buttons are replaced by a **Close** button.

The **Read Template** button opens a text file with metadata keys, stored as one key and its description (separated by one or more TAB characters) per text line. A template for the above metadata would be:

```
MyHeader1=
Author*
Company Dassault Systèmes
Copyright 2022
License
MyHeader2=
```

Note. The existing keys and descriptions are erased when reading a template file.

### **3.2.3 Support of Markdown for documentation**

Markdown is supported for documentation, you can activate it by the command **Documentation > Markdown**:



For more information about basic Markdown, see https://www.markdownguide.org.

Note that equations in Latex and MathML are supported. MathJax is used for rendering. An example of Latex text with equations:

#### The editor is shown in the first image below, the formatted text in the second image:





Note that there is an option to change the rendering by right-clicking any equation:



MathJax is by default activated by the flag Advanced.Editor.MathJax=true.You can set the flag to false to deactivate MathJax.

### **3.2.4 Minor improvements**

#### **Privacy of UML generation**

The **Tools > UML** command uses an external service (yuml.me) to do the formatting and presentation of the UML diagram. This means that certain information from the user's model, such as model names, is passed to some external server on the Internet. While the use of this command is voluntary, there is a risk that user might select the command by mistake (especially so from the model's context menu).

To prevent this from happening, the user is now, by default, asked for confirmation when applying the UML command. This corresponds to the flag

```
Advanced.UI.AllowExternalServer = 1
```

By setting the flag to 0, the UML command is disabled, and removed from the menu. By setting the flag to 2, the command is allowed without asking for confirmation.

#### Improved handling of the amount of information in the error log

In previous versions of Dymola you could not decide the level of information displayed, an example is the very simple model:

```
model Unnamed
Boolean test;
equation
test = 1;
end Unnamed;
```

The error message was:

	(i) Check of <u>Unnamed</u> :
	🔀 For equation
>	test = 1;
	found in class Unnamed, declaration window at line 4.
	<ol> <li>Basic type inconsistencies detected.</li> </ol>
	<ol> <li>Check aborted.</li> </ol>
	😢 ERRORS have been issued.
	-

To understand the problem just looking at that text was not all clear, you had to expand it:

	i	Check of Unnamed:
	8	For equation
$\sim$		test = 1;
		found in class <u>Unnamed</u> , declaration window at line <u>4</u> .
		$\bigotimes$ The types of the operands in (test) = (1)
		are Boolean and Integer, but they must be compatible.
		(i) Variable test was declared in class <u>Unnamed</u> , declaration window at line <u>2</u> .
	i	Basic type inconsistencies detected.
	i	Check aborted.
	8	ERRORS have been issued.

For Dymola 2023, you can use the flag Advanced.UI.AutoOpenLog to decide to what level the messages in the error log are expanded:

- 0 (default) No expansion, like in previous Dymola versions.
- 1 First level of warnings and errors are expanded.
- 2 All levels of warnings and errors are expanded.

Note that the last alternative corresponds to right-clicking the log text and selecting **Expand All.** However, this expansion is only kept until the next check, the flag value is kept during the session.

The previous header "For equation" has also been changed to "Type error for equation" to make the message more clear. So, setting the flag Advanced.UI.AutoOpenLog = 1 and checking the above model in Dymola 2023 automatically gives:



#### Improved checking for overriding final modifiers

The check for overriding final modifiers has been improved to detect if a parameter declared as final in a record is overridden by setting the entire record (unless this gives the same value).

However, to be compatible with current libraries, the check is currently skipped for replaceable parameter records (that contain final parameters).

If you are developing libraries using such parameters, please contact Dassault Systèmes support at <u>https://www.3ds.com/support</u> for instructions.

# **3.3** Simulating a model

#### **3.3.1 Better presentation of timers**

#### General

In Dymola 2023, most block timers are now printed to dsmodel.mof if the following flags are set:

```
Advanced.GenerateBlockTimers = true;
Advanced.OutputModelicaCode = true;
```

(By default, there flags are false.)

The block numbers match those in the simulation log.

When the new flag Advanced.Debug.WriteTimerResultsToFile is set to true, the results of any timers will be printed, as a semi-colon separated list, to the file timers.txt, in addition to the printout in the simulation log. The flag is by default true. Currently, the text file is updated once per second when simulating, if timers are generated.

The handling of precision timing is improved, precision timers are only used when any timers are generated (that is, when any of the flags Advanced.GenerateBlockTimers, Advanced.GenerateFunctionTimers, or Advanced.GenerateTimers are set to true). This means that if no timers are generated, the time reported in the normal simulation statistics in the simulation log does not use precision timing. Given this, the default value of the flag Advanced.Define.PrecisionTiming is now changed to true, since if no timers are generated, the precision timing is not used anyway. The advantage is that you don't have to care about the value of this flag anymore.

#### Simulation setup options for timers

Simulation Setup ? ×	
General Translation Output Debug Compiler Realtime FMI Export FMI Import	
General simulation debug information	
<ul> <li>Normal warning messages</li> <li>Debug settings included in translated or exported model</li> <li>Store variables after failed initialization</li> <li>Include function call in error messages</li> </ul>	
Simulation analysis Timers	
<ul> <li>□ Events during initialization and simulation</li> <li>□ Which states that dominate error</li> <li>□ Provide variable dependencies and equation incidence</li> </ul>	
Nonlinear solver diagnostics	
<ul> <li>Detailed logging of failed nonlinear solutions</li> <li>Nonlinear solution summary</li> <li>Nonlinear solution</li> <li>Nonlinear iterations</li> <li>Details</li> <li>Log singular linear</li> </ul>	
State variable logging	
Dynamic state selection     Final selection of states	
Min/Max assertions All variables Non-linear iterations variables Allowed error 0 Use bounds for simplification Log when using bounds for simplification	
Store in Model  Automatically store General and Inline integration settings OK Cancel	]

The simulation setup dialog (reached by the command **Simulation > Setup**) now contains a new group **Timers**, with options to activate block timers, and function and FMU timers, respectively. The settings are by default not activated.

The options correspond to the flags Advanced.GenerateBlockTimers and Advanced.GenerateFunctionTimers.

#### Presentation of timers in the simulation analysis dialog

If timers are active (by any of the previously mentioned flags and settings), and the flag Advanced.Debug.WriteTimerResultsToFile is set to true, the timer values are

presented in the Simulation Analysis dialog, in the new tab **Timers**. The tab has two subtabs, **Block timers**, and **Function and FMU timers**. If you open the demo Coupled Clutches and simulate it, the dialog can look like:

ot Dependencies	Equation Incidence	e Numeric Ir	ntegration	Event Log	Timers	
nulation timers read	l after the end of t	he simulation at t	ime = 1.5 s.			
Block timers Fu	nction and FMU tim	ers				
Name of block	Block number	Total CPU [s]	Mean [µs]	Min [µs]	Max [µs]	Number of calls
Entire model	0	0.007	1.52	0.15	284.12	4570
Event handling	1	0.000	16.72	2.58	283.92	29
Empty timer	2	0.000	0.01	0.00	0.16	4570
Outside of mod	lel 3	0.072	15.76	0.10	2368.38	4569
> Parameters	4	0.000	41.02	41.02	41.02	1
> InitialSection	10	0.000	173.45	173.45	173.45	1
> DynamicsSection	on 42	0.005	1.66	0.80	108.32	3048
> AcceptedSectio	n1 71	0.000	0.09	0.04	16.58	1969
> AcceptedSectio	n2 73	0.000	0.08	0.04	18.79	1969

The timer values are automatically read from the file timers.txt at the end of the simulation (regardless if the simulation succeeded of failed). For long simulations, you can use the **Refresh** button to read the timer values during the simulation.

The most significant contributions to the total time are highlighted in red. The more intense the color, the more time measured by the timer.

By clicking **Expand Highlighted**, all highlighted timers are expanded; this makes it easier to identify the most critical blocks and functions. (You can also **Expand All** or **Collapse All** timers.)

By right-clicking a timer and selecting **Expand All Levels**, the selected item and all its sublevels are expanded.

By clicking the headers, the data can be sorted according to the values in the selected column.

## 3.3.2 Steady state solver interface

#### Specifying a start time for dynamic steady-state finding

Steady State		×			
Simulation mode					
<ul> <li>Dynamic simulation</li> <li>Static steady-state findir</li> <li>Dynamic steady-state fi</li> </ul>	5				
Model manipulation					
Default steady-state initi Remove "fixed = true" f	i <b>alization</b> from continuous variables				
Steady-state detection tolera	nce				
Default     Tolerance:     Strict     Custom	)2	1/s			
Detection and verification —					
Fail if steady state not a	chieved				
Start steady-state finding a	t time: Start time	S			
Result and plot options					
Write variables to result Compare steady-state r					

The steady-state solver interface (reached by the command **Simulation > Steady State**) has been extended with a new option **Start steady-state finding at time**: for the **Dynamic steady-state finding** mode. This option sets a start time for the dynamic steady-state finding. That is, Dymola will not start to look for a steady state during simulation until the specified time is reached. This can be useful if a model starts in a steady-state, but an event triggers dynamic behavior at a time later than the start time of the simulation. By default, Dymola will start the steady-state detection from the beginning of the simulation. Changing this setting causes a retranslation. The setting corresponds to the flag Advanced.Simulation.SteadyStateTerminationStartTime.

# Activating strict steady-state detection tolerance for dynamic steady-state finding

There is now an option to use a stricter tolerance for the mode Dynamic steady-state finding:

Steady State			×					
Simulation mode								
<ul> <li>Dynamic simulation</li> <li>Static steady-state finding</li> <li>Dynamic steady-state finding</li> </ul>								
Model manipulati	on							
	<b>dy-state initialization</b> red = true" from con	tinuous variables						
Steady-state det	ection tolerance							
🔿 Default	Tolerance:							
🔍 Strict	Strict: 0.0001		1/s					
் Custom								
Detection and ve	rification							
	v state not achieved ate finding at time:	Start time	s					
Result and plot o	ptions							
<ul> <li>Write variables to result file only at stop time</li> <li>Compare steady-state results</li> </ul>								

ThesettingcorrespondstotheflagAdvanced.Simulation.SteadyStateTerminationStrict=true. Changing to thisstricter tolerance does not require re-translation. It also works with FMI export.

The new feature is the **Strict** option. However, to clarify that option, also the options already present (**Default** and **Custom**) must be clarified:

When performing a **Static steady-state finding**, the **Default** tolerance is 1e-8. This value can be seen in the **Tolerance** field, preceded by the text Default:. During simulation, the value is scaled by state variables (the size of the states) and nominals.

When performing a **Dynamic steady-state finding**, the **Default** tolerance is 2e-2 (or 1e-4 if **Strict** is selected). The tolerance is then scaled according to the temporal scale of the problem (derived from the output interval and simulation start and stop time). This allows for quick enabling of **Dynamic steady-state finding** out-of-the-box. The result of this time scaling can be seen in the **Tolerance** field, preceded by the text Default: or Strict: to indicate if **Default** or **Strict** tolerance has been selected. During simulation, also the size of states and their nominals are scaling the value, for both selections.

For both **Static steady-state finding** and **Dynamic steady-state finding**, you can set a **Custom** tolerance. During simulation, also the size of states and their nominals are scaling the value, but the value is not rescaled in time. This allows for subsequent modification of stop time and number of output intervals without affecting the **Dynamic steady-state finding**.

For example, it allows for setting a large stop time to minimize the risk of hitting the stop time before a steady state is reached.

The custom tolerance can be seen and changed in the **Tolerance** field, with no preceding text. The value corresponds to the value of the flag Advanced.Simulation.SteadyStateTerminationTolerance. If the **Custom** mode is not selected, which is default, the value of the flag is 0.

Notes:

- Using and changing the custom tolerance requires re-translation.
- Custom tolerances also work with FMI export.
- If you click the **Tolerance** field, and start entering a value, you automatically change the tolerance mode to **Custom**.

Please note the extended tooltip for the Steady-state detection tolerance group:

Steady	State	<b>c</b>
Simulati	ion mode	-
🔿 Sta	rnamic simulation atic steady-state finding rnamic steady-state finding	
Model r	nanipulation	-
	fault steady-state initialization move "fixed = true" from continuous variables	
Steady	-state detection tolerance	-
De		
O St	rict Default: 0.02 1/s	
0 C	Tolerance for steady-state detection and verification.	
Detecti Fa	The default tolerance used to check for non-zeros state d the option "Static steady-state finding" is 1e-8, scaled by s nominals.	erivatives when using state values and
Result a	When performing a "Dynamic steady-state finding" the de	
	is used (or 1e-4 if "Strict" is selected). This tolerance is so temporal resolution of the problem (as determined by out	aled according to the out interval and
	simulation start and stop time). The result of this scaling is "Tolerance" text edit. When applied in the simulator state are also considered.	shown in the
	For both "Static steady-state finding" and "Dynamic stead custom tolerance can be set. State sizes and nominals will However, the user-specified custom tolerance will not be r allows for subsequent modification of stop time and numb without affecting the "Dynamic steady-state finding".	likewise be applied. escaled in time. This

#### Steady-state solver interface improvements

The steady-state solver interface has been simplified and clarified.

The options **Stop simulation at time:** and **Number of results to keep** have been removed from the steady-state solver interface. (They are still available in the Simulation Setup and, for the former option, also in the **Simulation** ribbon.)

The option **Steady-state detection tolerance** has been extended to a group with the same name. The group clarifies previous options, and includes the new **Strict** option. See previous section for details.

### 3.3.3 Max run time per simulation

There is now a new option to specify max run time for individual simulations. That is, each simulation gets its own built-in timer. In both cases, wall-clock time is used.

Simulation Setup		?	$\times$
General Translatio	n Output Debug Compiler Realtime FMI Export	FMI Imp	port
Experiment			
Model	Modelica.Mechanics.Rotational.Examples.CoupledClutches		
Result	CoupledClutches		
Max simulation run tim	ie		
For batch	Not set		s
Per simulation	Not set		s
Simulation interval			
Start time	0		s
Stop time	0		s
Steady State			
Output interval			
• Interval length	0.001		s
<ul> <li>Number of interv</li> </ul>	als 0		
Integration			
Algorithm	Dassl	$\sim$	
Tolerance	0.0001		
Fixed Integrator Ste	0		s
Store in Model Auto	matically store General and Inline integration settings OK	Ca	ancel

The option **For batch** existed already in previous versions of Dymola. A single timer is used, which is managed by Dymola. For a batch of runs, e.g. sweep parameters, there is one timer and all simulations will be stopped when that timer runs out. Changing this timer does not require re-translation.

The **Per simulation** option is new for Dymola 2023. Each simulation gets its own timer. Each simulation starts its own timer with the specified time when it starts the simulation and stops itself if this timer runs out. This option may be useful if a few of the simulations in a sweep takes very long time and eventually fails. Then these can be automatically stopped early, without affecting the other simulations. (Please compare with the **For batch** alternative, where an early simulation taking a long time may consume all available time for the batch, leading to any remaining simulations not being executed.)

The option **Per simulation** is embedded in the simulator, including an exported FMU, and is therefore independent of Dymola running the simulation. Changing this option requires retranslation.

The logging of both options has also been improved. See the following excerpts from the simulation log:

```
... Error message from dymosim
Stopping simulation after reaching max run time.
(Stop requested by Dymola.)
```

```
... Error message from dymosim
Stopping simulation after reaching the embedded
max run time (4 seconds) for this simulator.
```

## 3.3.4 Scripting

#### Scripting support for creating plot

The built-in function createPlot now has an additional argument plotInAll. This argument is already available in the built-in function plot. If you set this argument to true, all open result files will be searched for the variables specified to be plot, and all found occurrences are plotted. This is useful if you want to compare the result of different simulations.

#### **Built-in function clearFlags improved**

The built-in function clearFlags() has been improved; it does not reset the flag Advanced.SaveSettings. This prevents possible problems when starting Dymola with the command line option -nosavesettings and then using clearFlags().

#### Improved saving of models by scripting

The built-in function saveModel for saving a model by scripting has been improved.

You can now store in the current model (like "**Ctrl+S**") by setting the argument path to an empty string "". (The argument has no default; you have to provide a path.)

A new integer input argument storeVariant has been added, the possible values are:

- 0: save the model as one .mo file (default value)
- 1: save the model in directories
- 2: keep current structure of the model when saving

#### Scripting support for importing SSV files

You can import SSV files by the new built-in function importSSV. For details, see section "Importing SSV files by scripting" on page 46.

### 3.3.5 Minor improvements

#### Improved handling of the "smooth" operator for some solvers

The handling of the "smooth" operator has been improved for a number of solvers. This may reduce the number of events and improve performance for models that use "smooth".

The solvers improved are the "Godess" solvers, that is, the solvers:

- Radau IIa
- Esdirk23a
- Esdirk34a
- Esdirk45a
- Dopri45
- Dopri853
- Sdirk34hw
- Cerk23
- Cerk34
- Cerk45

Note that other solvers already have the above improvement.

#### Nonlinear solver statistics available for plotting

In previous versions, a setting was available to include CPU time and simulation events in the simulation results. The setting has now been renamed to **Include variables for CPU time**, **event counting, and nonlinear solver statistics**, to reflect both the old feature of including number of events, as well as including the new nonlinear system diagnosis.

The setting is available in the simulation setup, reached by the command **Simulation > Setup**, the **Translation** tab. The setting corresponds to the flag Advanced.Translation.OutputCPUtime = true. (The value is by default false.)

When activated, except including CPU time and event counting, four new variables are created for each nonlinear system in the model. These variables can be found in the variable browser (see last image in this section)

These variables contain exactly the same diagnostics as is given in the simulation log by setting **Nonlinear solution summary** in the **Debug** tab of the simulation setup, but now it is possible to plot the diagnostics over time to see where the most effort is spent.

For the example Modelica.Mechanics.MultiBody.Examples.Loops.EngineV6:

The nonlinear solution summary in the log:

Logs					×
Nonlinear solver summary, acc	umulate	d amounts:			^
Tag	Calls,	Residues,	Iterations,	Jacobians	
initialization.nonlinear[1]	1,	7,	7,	1	
initialization.nonlinear[2]	1,	7,	7,	1	
initialization.nonlinear[3]	1,	2,	2,	1	
initialization.nonlinear[4]	1,	7,	7,	1	
initialization.nonlinear[5]	1,	2,	2,	1	
initialization.nonlinear[6]	1,	7,	7,	1	
simulation.nonlinear[1]	40578,	131649,	131649,	40578	
simulation.nonlinear[2]	40578,	129865,	129865,	40578	
simulation.nonlinear[3]					
simulation.nonlinear[4]	40578,	129740,	129740,	40578	
simulation.nonlinear[5]	40578,	131537,	131537,	40578	
simulation.nonlinear[6]					
To also log used CPU-times en	nable Ad	vanced.Gen	erateBlockTi	mers.	
-					×
Syntax Translation Simulation	Version				

The corresponding variables in the variable browser, with two signals plotted:



We can see from the plot that the equation is called more often as the simulation proceeds; the number of residual calculations seems to be explained by the increased number of calls to the equation.

# Improved handling of start guesses for variables that describe the discrete state of mixed systems of equations

Save Start Values in Model	?	×
Source for start values		
<ul> <li>Current Variable Browser content</li> <li>Initialize the model and save the results</li> </ul>		
Store options		
<ul> <li>Store values in current model</li> <li>Store values in new model</li> </ul>		
Name:		
MyCoupledClutches		
Description:		
Drive train with 3 dynamically coupled clutches Extends:		
MyCoupledClutches		
Insert in package:		
	$\sim$	+0 0 +0
Open new class in:		_
This tab		$\sim$
Advanced options for storing start guesses		
Save changes in parameters and in initial value	ies of state	s
Overwrite parametrized start attributes for be	elow selection	on
Additionally, save changes in the start attributes	of:	
<ul> <li>Iteration and mixed system variables</li> <li>Iteration, torn, and mixed system variables</li> <li>Outputs, auxiliary variables, and states</li> <li>Only save start guesses for additional variab</li> </ul>	les at start	
Other useage may cause unwanted changes parametrization. These advanced options ar saving start guesses and must not be used simulations from times later than the start ti	e only inter to continue	nded for
Advanced << OK	(	Cancel

Already in Dymola 2022x you could select to store start guesses for variables that describe the discrete state of mixed systems of equations. In the above framed selection, the added text "mixed system" indicates this. This improvement makes it possible to store in which discrete configuration a mixed system is in after initialization.

Note that you can, from Dymola 2022x, also edit these start guesses in the variable browser.

#### Improved start-value priority

The handling of start value priority has been improved; the start-value priority has been updated to also consider the parameter-level if the start-value is bounded to a parameter. (This

change can be disabled by setting the new flag Advanced.Translation.UseParameterLevelForStartValue = 0. The default value of the flag is 2, meaning that parameter-level is considered everywhere. You can also set the flag to 1, that means only use parameter-level for non-iteration, trusting literals more.)

You can now also get an overview of the prioritized conflicting start-values setting the new flag:

```
Advanced.Translation.LogStartValuePriority = true
```

(The flag is by default false.)

#### Time range filter for Simulation Analysis Numeric Integration

There may be different states dominating the error during different times of the simulation. It is now possible to limit the time range of the integrator diagnostics data. This makes it possible to see, in the summary, what is relevant for the chosen time interval. For the corresponding plots, the benefits are that it is faster to zoom in at the interesting range and that downsampling of the plot data may be avoided. This reduces the risk of missing something important.

The numeric integration is reached by the command **Simulation > Simulation Analysis**, the **Numeric Integration** tab:

Simulation Analys	is					-		>
Plot Dependencies	Equation Incide	nce	Numeric Ir	ntegration	Event Log			
Simulation statistics	read after the end	of the	e simulation a	t time = 1.5	s.			
Variable	Limits Step Size	Dom	nates Error	>10 % of	Error			
clutch1.phi_rel	0		3					9
clutch1.w_rel	3		95				9	8
clutch2.phi_rel	0		0					0
clutch3.phi_rel	0		3					29
clutch3.w_rel J1.phi	0		33 0					16 0
J1.w	1		9				14	
Start time: 0.5		S I	1	•			Apply	
Stop time: 1.0		S ,	I	I			1,664	
Plot Integrator Step	) Size				F	Refresh	Close	2

You can use the sliders to set the start time and stop time of the range, or enter the values directly in the value fields. Click **Apply** to use the selected range.

The values presented in the summary will be limited to the data gathered in the specified time range. Step size and error plots will also be limited to the specified range.

Note that the limits are specified inside Dymola and doesn't limit the output from the integrator.



Example of an error plot from clutch1.w rel for the above range:

Example for the integrator step size for the above range:



# Plotting error with the state derivative instead of the state itself for Simulation Analysis Numeric Integration

For numeric integration of simulation analysis, you can now plot error with the state derivative instead for the state itself, by the context command **Plot Error with Derivative**:

Plot Dependencies	Equation Incide	nce Numeric I	ntegration	Event Log		
Simulation statistics	read after the end	of the simulation a	at time = 1.5 s	5.		
Variable	Limits Step Size	Dominates Error	>10 % of Er	ror		
clutch1.phi_rel	0	39				81
clutch1.w_rel	6	258	N			271
clutch2.phi_rel	0	1	· Plot Erro	r With State		14
clutch3.phi_rel	0	14	Plot Erro	r With Derivative		41
clutch3.w_rel	0	33	Plot Dep	endencies	-	46
J1.phi	0	0				42
J1.w	3	9	Show Co	mponent clutch1	.w_rel ►	315
J1.w Start time: 0 Stop time: 1.5	3	9 s •	Show Co	mponent clutch1		315

(The numeric integration is reached by the command **Simulation > Simulation Analysis**, the **Numeric Integration** tab.)

The result of the command is:



# Improved handling of alias names of variables in error messages and other outputs

In Dymola 2023, the use of alias names of variables is improved. You can use the new flag Advanced.Translation.KeepAliasInMessages to decide what to present.

The value of the flag can be:

- 0: Use alias name in texts; this value corresponds to the alias name use in previous Dymola versions.
- 1: Use original variable name in texts; this is the default value of the new flag.
- 2: Use alias name in texts, but also present the original variable name as comment in the texts.
- 3: As "2", but use this also in dsmodel.mof.

The flag is used when creating error messages, information messages, logging, plot dependency information, and equation incidence texts.

As an example, consider equation incidence with the flag value 2:

Plot Dependencies       Equation Incidence       Numeric Integration       Event Log         Equation block:       11.flange_a.tau /* originally: sin1.y*/ = sin1.offset+(if time < sin1.startTime then 0 else sin1.ampitude*sin(6.283185307179586*(sin1.f*(time-sin1.startTime))+sin1.phase));       >> Solution of a mixed system of integer or boolean equations with simulation.lnear[1]         Image_a.tau /*       Image_a.tau /*       Image_a.tau /*       Image_a.tau /*       Image_a.tau /*         Unknowns       Type/Unit       Image_a.tau       Image_a.tau       Image_a.tau       Image_a.tau         Alias       Type/Unit       Alias to       Image_a.tau       Image_a.tau       Image_a.tau         Y       N.m       J1.flange_a.tau       Image_a.tau       Image_a.tau       Image_a.tau       Image_a.tau         Stock color explanation:       Image_a.tau       Image_a.		is					-		>
J1. flange_a.tau /* originally: sin1.y*/ = sin1.offset+(if time < sin1.startTime then 0 else	Plot Dependencies	Equation 1	Incidence	Numeric Integrat	tion	Event Log			
Unknowns Type/Unit   Viknowns Type/Unit   Y J1   flange_a.tau N.m   J1.flange_a.tau   Kixed   flange.tau   N.m   J1.flange_a.tau   Vorque   flange.tau   N.m   J1.flange_a.tau   Vorque   flange.tau   N.m   J1.flange_a.tau   Support.tau   N.m   J1.flange_a.tau   Block color explanation:   Linear Non-linear Mixed Dummy Scalar	J1.flange_a.tau /* sin1.amplitude*sin(	(6.283185307	'179586*(sir	1.f*(time-sin1.star	tTime)	)+sin1.phas	e));		
Unknowns Type/Unit V J1 flange_a.tau N.m Alias Type/Unit Alias to V fixed flange.tau N.m -J1.flange_a.tau V sin1 Y N.m J1.flange_a.tau V torque flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala	O O O O O O     O	0000				••••	000	000	
<ul> <li>✓ J1 flange_a.tau N.m</li> <li>Alias Type/Unit Alias to</li> <li>✓ fixed flange.tau N.m -J1.flange_a.tau</li> <li>✓ sin1</li></ul>								,	>
Alias Type/Unit Alias to $\checkmark$ fixed flange.tau N.m -J1.flange_a.tau $\checkmark$ sin1 $\checkmark$ N.m J1.flange_a.tau $\checkmark$ torque flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala		Type/Unit							
Fixed flange.tau N.m -J1.flange_a.tau v sin1 y N.m J1.flange_a.tau v torque flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scalar									
flange.tau N.m -J1.flange_a.tau v sin1 y N.m J1.flange_a.tau v torque flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala		u N.m							
<ul> <li>✓ sin1</li> <li>ý N.m J1.flange_a.tau</li> <li>✓ torque</li> <li>flange.tau N.m -J1.flange_a.tau</li> <li>support.tau N.m J1.flange_a.tau</li> <li>tau N.m J1.flange_a.tau</li> <li>Block color explanation:</li> </ul>	flange_a.ta		Alias to						
<ul> <li>✓ sin1</li> <li>ý N.m J1.flange_a.tau</li> <li>✓ torque</li> <li>flange.tau N.m -J1.flange_a.tau</li> <li>support.tau N.m J1.flange_a.tau</li> <li>tau N.m J1.flange_a.tau</li> <li>Block color explanation:</li> </ul>	flange_a.ta		Alias to						
<ul> <li>✓ torque flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau</li> <li>Block color explanation:</li> <li>Linear</li> <li>Non-linear</li> <li>Mixed</li> <li>Dummy</li> <li>Scala</li> </ul>	flange_a.ta Alias ✓ fixed	Type/Unit		_a.tau					
flange.tau N.m -J1.flange_a.tau support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala	flange_a.ta Alias V fixed flange.tau	Type/Unit		_a.tau					
support.tau N.m J1.flange_a.tau tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala	flange_a.ta Alias v fixed flange.tau v sin1	Type/Unit N.m	-J1.flange	_					
tau N.m J1.flange_a.tau Block color explanation: Linear Non-linear Mixed Dummy Scala	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1	Type/Unit N.m	-J1.flange	a.tau					
Block color explanation:	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1	Type/Unit N.m N.m	-J1.flange_i J1.flange_i -J1.flange	a.tau _a.tau					
	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1	Type/Unit N.m N.m N.m	-J1.flange_i J1.flange_i -J1.flange_ J1.flange_i	a.tau _a.tau a.tau					
	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1 ✓ v torque flange.tau support.tau	Type/Unit N.m N.m N.m J.M.m	-J1.flange_i J1.flange_i -J1.flange_ J1.flange_i	a.tau _a.tau a.tau					
7 Zoom out the incidence matrix 🔽 Rotate the incidence matrix 45° 🗌 Compact View 🔤 Close	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1 ✓ torque flange.tau support.tau tau	Type/Unit N.m N.m N.m J.M.m N.m	-J1.flange_ J1.flange_ -J1.flange_ J1.flange_ J1.flange_	a.tau _a.tau a.tau a.tau					
Loon out the medianee made in the medianee made in the medianee made in the medianee medianee in the medianee made in the medianee medianee in the medianee in the medianee medianee in	flange_a.ta Alias ✓ fixed flange.tau ✓ sin1 ✓ torque flange.tau support.tau tau	Type/Unit N.m N.m N.m J.M.m N.m	-J1.flange_ J1.flange_ -J1.flange_ J1.flange_ J1.flange_	a.tau _a.tau a.tau a.tau	Mb	xed 📕	Dummy		Scala

In the equation block (top pane), the alias name Jl.flange\_a.tau is used, and the original value sinl.y is presented in a comment.

The fourth pane is new; here the aliases are presented, for the selected block.

#### Listing possible event-triggering expressions

If you activate the new setting **List event-triggering expressions** in the **Translation** tab of the simulation setup (reached by the command **Simulation > Setup**), then all expressions that may trigger events are listed under Translation statistics in the translation log.

Simulation Setup		×
	mport	
Model translation		_
Store in Model  Automatically store General and Inline integration settings OK	Cance	I

The setting is by default not activated. This corresponds to the flag Advanced.Translation.Log.EventExpressions = false.

An example of the translation log from simulating Modelica.Mechanics.Rotational.Examples.LossyGearDemo1 with the above setting activated:


Note that the list in the translation statistics do not include input time events and dynamic state selection events.

Note also that these expressions only potentially may trigger events. It may be that only a subset actually triggers events during simulation. To check which event-triggering expressions actually *did* cause events during a particular simulation, consider the **Event Log** tab in the simulation analysis dialog.

#### Improved synchronizing of writing and reading the simulation result file

In previous Dymola versions, the frequency of online reading of results from the simulation result file (for example, to update plots) was specified by the setting **Load result interval** in the **Realtime** tab of the simulation setup (reached by the command **Simulation > Setup**).

Simulation Setup ?	×
General         Translation         Output         Debug         Compiler         Realtime         FMI Export         FMI Import	t
Realtime simulation	_
Synchronize with realtime	
Slowdown factor 1	
Load result interval [s] 0.5	
Inline integration	_
Inline integration method not used	e
Runge Kutta order 2	2
Optimize code for step size 0.001	
Store in Model Automatically store General and Inline integration settings OK Can	el

In Dymola 2023, this is still the case, but now also the writing of values to the simulation result file is specified by this setting. This make the simulation of some models less time-consuming.

Note that the default value of 0.5 seconds is suitable in most cases. If you set a lower time, this may slow down the speed of the simulation.

#### Use of inline integration displayed in simulation log

In Dymola 2023 the simulation log includes information about if an inline solver is used, and in that case, which inline solver. An example:



## 3.4 Installation

For the current list of hardware and software requirements, please see chapter "Appendix – Installation: Hardware and Software Requirements" starting on page 50.

## 3.4.1 Installation on Windows

#### Checking selected license server in the license setup

To be able to check the selected license server in the license setup, there is now a new button **Verify** that performs the same check as is done when you select and apply a new license server.

This makes it possible to:

- Checking the present license server.
- Checking a selected license server before applying it.

Note that also DSLS license servers can be checked.

Dymola License Set	up				?	×
General Details	Borrow	Setup				
License server						
Server name(s)	ell697cem.d	sone.3ds.	com			
Port (optional)	y default or	e of 2700	0-27009			
	Verify					
Local license file						_
File name ;/uw Browse	/m/appdata	/roaming/	dassaultsyst	emes/dym	ola/dymola	a.lic
Install license for all u	users					
Install for all use	ers (requires	administr	ator rights)			
				OK	Ca	ncel

## 3.4.2 Installation on Linux

#### Checking selected license server in the license setup

See the corresponding section in "Installation on Windows".

## 3.4.3 Dymola license server on Windows and Linux

#### Upgrade of FLEXnet Publisher version (on Windows and Linux)

FLEXnet Publisher in Dymola 2023 is upgraded to version 11.16.2.1. Therefore, the FLEXnet Publisher license server used for Dymola must also be upgraded to a version number at least 11.16.2.1, to be compatible. To do this, do the following:

- Copy the new vendor daemon (dynasim.exe) to the license server.
- Update lmgrd.exe to version 11.16.2.1.
- Restart the license server.

The updated FLEXnet Publisher enables you to work on for example (for Windows) Windows Server 2019.

Note that FLEXnet Publisher license server 11.16.2.1 works with previous Dymola versions as well.

#### 64-bit license server (on Windows and Linux)

The 32-bit license server on Windows is replaced by a 64-bit license server. The primary reason for this is to be consistent with Linux, where newer versions will only be provided as 64-bit.

#### The web-based license server Imadmin removed (on Windows and Linux)

On Windows and Linux, the web-based FLEXnet license server manager lmadmin is removed from the Dymola distribution. You can still use the command line based lmgrd. Note that you can yourself download lmadmin if you want to.

## **3.5 Model Experimentation**

### 3.5.1 Improvements for sweeping parameters

#### Improved display unit handling for sweeping

The following improvements for handling of display units for sweeping have been implemented:

#### Display and change option for display unit for plotted variables in the sweeping dialog

The display unit is now displayed also for plotted variables:

Sweep Parameters	×				
E Parameters to sweep					
☑ f [Hz]					
linspace(0.1, 0.3, 3)					
🗇 Variables to plot					
☑ J1.der(phi) [rad/s]	$\sim$				
○ Trajectory					
Run Sweep					

You can change the display unit for a plotted variable by clicking on it, like for parameters to sweep:

Sweep Parame	ters	×
🕼 Parameter	s to sweep	
✓ f [Hz]		
linspace(0.1, 0	.3, 3)	
🗇 Variables 🕯	to plot	
✓ J1.der(phi)	Nrad/s	X
	S <sup>rad/s</sup> ⁰/s	
	rpm	
	1/min	
	r/min	
Trajectory	1/s	ast Point
	Hz	
	Run Sweep	

#### Selection of display units respected and displayed in the sweeping plots

The choices of display units of parameters to sweep and variables to plot are respected and displayed in the resulting plot. As an example, for sweeping one parameter, last point:



#### For sweeping one parameter, options to change the display units after the sweep

When you sweep one parameter, you can change the display unit of the plot variables after the sweep, by either right-clicking the corresponding curve and selecting **Display Unit**, or



selecting the curve and using the Display Unit button of the Plot ribbon. An example of the former:

To change the display unit of the swept parameter, you can right-click in an empty space in the plot window and select **Horiz Display Unit**:



Note that changing display units after the sweep is not possible when sweeping more than one parameter.

## **3.6 Other Simulation Environments**

#### **3.6.1** Dymola – Matlab interface

#### Compatibility

The Dymola – Simulink interface now supports Matlab releases from R2017a (ver. 9.2) up to R2021b (ver. 9.11). On Windows, only Visual Studio C++ compilers are supported to generate the DymolaBlock S-function. On Linux, the gcc compiler is supported. The LCC compiler is not supported, neither on Windows nor on Linux.

### 3.6.2 Real-time simulation

#### **Compatibility – dSPACE**

Dymola 2023 officially supports the DS1005, DS1006, MicroLabBox, and SCALEXIO systems for HIL applications. For these systems, Dymola 2023 generated code has been verified for compatibility with the following combinations of dSPACE and Matlab releases:

- dSPACE Release 2017-A with Matlab R2017a
- dSPACE Release 2017-B with Matlab R2017b
- dSPACE Release 2018-A with Matlab R2018a
- dSPACE Release 2018-B with Matlab R2018b
- dSPACE Release 2019-A with Matlab R2019a
- dSPACE Release 2019-B with Matlab R2019b
- dSPACE Release 2020-A with Matlab R2020a
- dSPACE Release 2020-B with Matlab R2020b
- dSPACE Release 2021-A with Matlab R2020b and R2021a
- dSPACE Release 2021-B with Matlab R2020b, R2021a, and R2021b

The selection of supported dSPACE releases focuses on releases that introduce support for a new Matlab release and dSPACE releases that introduce a new version of a cross-compiler tool. In addition, Dymola always support the three latest dSPACE releases with the three latest Matlab releases. Although not officially supported, it is likely that other combinations should work as well.

#### New utility functions - dym\_rti\_build2 and dym\_rtimp\_build2

Dymola 2021 introduced a new function, dym\_rti\_build2, that replaces dym\_rti\_build for building dSPACE applications from models containing DymolaBlocks. The new function uses the new dSPACE RTI function rti build2 instead of the old function rti build.

A corresponding new multi-processor build function,  ${\tt dym\_rtimp\_build2},$  is also introduced.

These functions are supported with dSPACE Release 2019-B and later.

#### Note on dym\_rti\_build and dSPACE Release 2017-A and later

The function rti\_usrtrcmerge is no longer available in dSPACE Release 2017-A and later. As a consequence, it is required to run the standard rti\_build function (with the 'CM' command) after dym\_rti\_build to get your \_usr.trc content added to the main .trc file. For example:

```
>> dym_rti_build('myModel', 'CM')
>> rti build('myModel', 'Command', 'CM')
```

Note that this note applies the new functions dym\_rti\_build2 and rti\_build2 as well.

#### **Compatibility – Simulink Real-Time**

Compatibility with Simulink Real-Time has been verified for all Matlab releases that are supported by the Dymola – Simulink interface, which means R2017a (Simulink Real-Time ver. 6.6) to R2021b (Simulink Real-Time ver. 7.2). Only Microsoft Visual C compilers have been tested.

## 3.6.3 Dymosim DLL

#### Postponed discontinuation of dymosim DLL support

Dymosim DLL is still supported in Dymola 2023. However, Dymola 2023 is the last planned Dymola version to support dymosim DLL. From the next Dymola version, Dymola 2023x, dymosim DLL is not supported. It is replaced by the use of FMI.

## 3.6.4 SSP support

#### **SSP** export

Dymola can export Modelica models according to the System Structure and Parametrization (SSP) file format. The details of SSP can be found at <u>https://ssp-standard.org</u>. Dymola performs the following steps when exporting to SSP:

- The top-level model structure is stored as a System Structure Description (SSD). That structure includes top-level components and connectors, and any connections between these.
- Components are stored in two formats depending on implementation.
  - If the component is an imported FMU, the FMU itself is copied to the resources directory of the SSP. The SSD will contain a reference to that FMU copy.
  - Otherwise, it is assumed that the component is represented by a Modelica model. In that case, the full path of the component's model is stored in the SSD. The Modelica model itself is not stored in the SSP file.

• Model documentation, user metadata annotation, parameter types, and component modifiers (including nested structures) are stored in the SSD.

SSP export is available by the command **File > Save > Export SSP**... or as the built-in function exportSSP.

#### **Importing SSV files**

The System Structure Values (SSV) file format is really a part of SSP, but it has gained interest as a freestanding entity. You can store model parameterizations in SSV files, and apply these parameterizations on Modelica files and FMUs.

The idea is:

- Start out with a Modelica model as your base model.
- Open an SSV file to read parameter data.
- Create a new Modelica model from the base model, applying the parameters (with values) as modifiers in an extends clause.

#### Importing SSV files by scripting

In Dymola 2023, you can import an SSV file by the new built-in function importSSV. The input arguments are:

- fileName a text string that is the name of the SSV file to import.
- modelName a text string that is the name of the existing (base) model that the parameters are applied to.
- packageName a text string that is the name of the Modelica package where the new model is to be inserted. (The name of the model is taken from the parameter set in the SSV file.) By default, this is an empty string, meaning that the created model is placed at the top level of the package hierarchy.

There is one output argument result. It is a text string that, in case of success, contains the full path of the created model. If the function call was not successful, the text string is empty.

#### Importing SSV files by a command

The existing command **File > Open > Import SSP**... can now also be used to import SSV files. When applying this command to an .ssv file (instead of an .ssp file), the command will call the importSSV function described above. The current root model will be used as the base model, and, by default, the newly created model is placed at the top level of the package hierarchy.

## 3.6.5 FMI Support in Dymola

Unless otherwise stated, features are available for both FMI version 1.0 and version 2.0.

#### **FMU** export

#### Max run time for an FMU

For this feature, see the option **Per simulation** in the section "Max run time per simulation" on page 24.

#### **FMU** import

#### Improved conversion options of unknown units for FMI 2.0

Two new flags are available for unit conversion when importing an FMU:

The flag Advanced.FMI.ConvertUnits is an integer flag that specifies when nonstandard Modelica units should be converted to their declared base units. The possible values of the flag are:

- 0 Don't convert any units.
- 1 (Default) Convert nonstandard units with factor 1 and offset 0.
- 2 Convert all nonstandard units. Units with factor !=1 and offset !=0 will have a different value in the Modelica wrapper.

The flag Advanced.FMI.LogAllIgnoredUnitConversions is a Boolean flag that is default false. If set to true, all units with skipped unit conversion will be listed.

#### Improved default value of the integration tolerance for FMI 2.0 Co-simulation FMUs

In previous Dymola versions, the default value of the integration tolerance of an imported FMU could be specified by the parameter fmi\_rTol which was sent into the function fmi2SetupExperiment. The default value used was le-6.

In Dymola 2023, you can select what default value to use by the new parameter  $fmi_setTol$ . The alternatives are:

- fmi\_setTol is false (default value): The value of the integration tolerance in the
  exported FMU is used as default integration tolerance. (The integrator tolerance in an
  exported FMU from Dymola is usually taken from the simulation setup.)
- fmi\_setTol is set to true: The parameter fmi\_rTol is used to set the default
  integration tolerance of the FMU. The default value of fmi\_rTol is the value given in
  the attribute tolerance of defaultExperiment in the modelDescription.xml, if
  this attribute exists. If it does not exist, the value le-4 is used.

## 3.6.6 eFMI Support in Dymola

Dymola now supports eFMI according to the public available <u>eFMI Version 1.0.0-alpha.4</u> specification. Dymola's eFMI facilities comprise generation of eFMUs with Algorithm Code, CATIA ESP based Production and Binary Code containers, and the usage of generated eFMUs for Co-simulation from within Modelica models.

The **eFMI** button in Dymola's **Tools** ribbon can be used to load Dymola's eFMI facilities (by the menu entry **Load Libraries...**)

🗋 🕼 🖱 ल % 🕑 🐼 🗔 =		DymolaEmbedded - DymolaEmbedded - [Documentation]					- 0	×	
File Graphics Documentation	Text Simulation	Tools					🔁 Wi	ndows 🔻 💽	- @ ×
To Clipboard Image Animation HTML	Graph Library Management	License Options Version Setup	Dymola s Website						
Package Browser 🗗 🗙	DymolaEmbedded >	× +		· · ·	× 😣 0 Error	s 🔔 0 Warning	is 🛈 0 Mes	isages	Clear
Model name Y lo *	Support library for Dyn	mola's eFMU generation facilities.		i i i	8				
> 🔁 DymolaCommands	Information								
> Favorites		library provides documentation, common utility	functions and applica	ation examples for the					
> 🚺 Modelica Reference		es of the <u>Dymola</u> Modelica-IDE.							
> 💯 Modelica	A detailed documentation	on is given in the <u>user's guide</u> .							
Unnamed	Important: Please note	the library requirements.		"Tools" ribbor	1 button	to load			
> efmi eFMI	Copyright			eFMI related libraries and					
> eFMI_TestCases				generate	e eFMUs				
> 🔁 DymolaEmbedded				-					
> eFMI_TestCases_EmbeddedConfi	ŚŚ	DASSAUL SYSTEMES	<b>T</b> 5						
	Copyright © 2016-2022	?, Dassault Systèmes							
	Extends from Icons.Dym	nolaEmbedded (DymolaEmbedded library icon	.).						
	Package Content								
	Name		cription		s				
H. 🗱 👍 📦 🐺	UsersGuide	User's guide (overview, requirements, release	e notes).		Syntax	Translation	Simulation	Version	
	E	A B B B B B B B B B B B B B B B B B B B	and the second second second						
Package Browser Component Browser	Examples	Application examples for Dymola's eFMU ger owser Steady State Sweep Parameters Comm			Commands	Logs			-

For eFMU generation, a Microsoft Windows Dymola installation must be used. A Dymola Source Code Generation License is required.

Further requirements, limitations, and documentation – in particular how to configure the eFMU generation - can be found in the "Users guide" of the DymolaEmbedded library. Just load the library via the **Load Libraries...** menu entry of the **eFMI** button in the **Tools** ribbon.

For an overview of eFMI, please see the paper <u>eFMI: An open standard for physical models</u> in embedded software.

## 3.7 Visualize 3D

## 3.7.1 Surface plots

## Using the generateMeshGrid function to generate parametric surface matrices

Already in previous Dymola versions, it was possible to format data for surface plotting, to be plotted by for example Plot3D.plotSurface. That was done using an internal function. This function is now made more visible by being added to the Utilities folder, as Plot3D.Utilities.generateMeshGrid. Help text is also added.

# **3.8 Modelica Standard Library and Modelica Language Specification**

The current version of the Modelica Standard Library is version 4.0.0. The current version of the Modelica Language Specification is 3.5.

Note that the Modelica Standard Library version 4.0.0 is compliant with the Modelica Language Specification 3.4.

## **3.9 Documentation**

#### New white paper: Using Windows Subsystem for Linux with Dymola

Already in Dymola 2022x this white paper was available. It describes the installation of Windows Subsystem for Linux (WSL) and the corresponding setup needed in Dymola. Information about the use of WSL in Dymola in included, as well as useful compiler options.

The paper is available using the command **Tools > Help Documentation**, under the section "White Papers". It is also available <u>here</u>.

#### General note about the manuals

In the software, distribution of Dymola 2023 Dymola User Manuals of version "March 2022" will be present; these manuals include all relevant features/improvements of Dymola 2023 presented in the Release Notes.

Limited Availability (LA) features are not documented in the manuals.

# **3.10** Appendix – Installation: Hardware and Software Requirements

Below the current hardware and software requirements for Dymola 2023 are listed.

## **3.10.1** Hardware requirements/recommendations

#### **Hardware requirements**

- At least 2 GB RAM
- At least 400 MB disc space

#### **Hardware recommendations**

At present, it is recommended to have a system with an Intel Core 2 Duo processor or better, with at least 2 MB of L2 cache. Memory speed and cache size are key parameters to achieve maximum simulation performance.

A dual processor will be enough if not using multi-core support; the simulation itself, by default, uses only one execution thread so there is no need for a "quad" processor. If using multi-core support, you might want to use more processors/cores.

Memory size may be significant for translating big models and plotting large result files, but the simulation itself does not require so much memory. Recommended memory size is 6 GB of RAM.

## **3.10.2** Software requirements

#### **Microsoft Windows**

#### Dymola versions on Windows and Windows operating systems versions

Dymola 2023 is supported, as 64-bit application, on Windows 8.1, and Windows 10. Since Dymola does not use any features supported only by specific editions of Windows ("Home", "Professional", "Enterprise" etc.), all such editions are supported if the main version is supported.

#### Compilers

**Please note** that for the Windows platform, a Microsoft C/C++ compiler, or a GCC compiler, must be installed separately. The following compilers are supported for Dymola 2023 on Windows:

#### *Microsoft C/C++ compilers, free editions:*

**Note**. When installing any Visual Studio, make sure that the option "C++/CLI support..." is also selected to be installed.

- Visual Studio 2012 Express Edition (11.0)
- Visual Studio 2015 Express Edition for Windows Desktop (14.0)
- Visual Studio 2017 Desktop Express (15) **Note!** This compiler only supports compiling to Windows 32-bit executables.
- Visual Studio 2017 Community 2017 (15)
- Visual Studio 2017 Build Tools Notes:
  - The recommended selection to run Dymola is the workload "Visual C++ build tools" + the option "C++/CLI Support..."
  - Installing this selection, no IDE (Integrated Development Environment) is installed, only command line features
  - This installation is not visible as a specific selection when later selecting the compiler in Dymola, the alternative to select is the same as for any Visual Studio 2017 alternative: Visual Studio 2017/Visual C++ 2017 Express Edition (15).
  - For more information about installing and testing this compiler with Dymola, see <u>www.Dymola.com/compiler</u>.
- Visual Studio 2019 Community (16)
- Visual Studio 2019 Build Tools Notes:
  - The recommended selection to run Dymola is the workload "C++ build tools" + the option "C++/CLI Support..."
  - Installing this selection, no IDE (Integrated Development Environment) is installed, only command line features
  - This installation is not visible as a specific selection when later selecting the compiler in Dymola, the alternative to select is the same as for any Visual Studio 2019 alternative: Visual Studio 2019/Visual C++ 2019 (16).
  - For more information about installing and testing this compiler with Dymola, see <u>www.Dymola.com/compiler</u>.

#### *Microsoft C/C++ compilers, professional editions:*

Note. When installing any Visual Studio, make sure that the option "C++/CLI support..." is also selected to be installed

- Visual Studio 2012 (11.0)
- Visual Studio 2015 (14.0)
- Visual Studio Professional 2017 (15)
- Visual Studio Enterprise 2017 (15)
- Visual Studio Professional 2019 (16)
- Visual Studio Enterprise 2019 (16)

#### Intel compilers

Note!

**Important.** The support for Intel compilers are discontinued from the previous Dymola 2022 version.

#### MinGW GCC compiler

Dymola 2023 has limited support for the MinGW GCC compiler. The following versions have been tested and are supported:

- For 32-bit GCC: version 5.3, 6.3, and 8.2
- For 64-bit GCC: version 5.3, 7.3, and 8.1

Hence, at least the versions in that range should work fine.

To download any of these free compilers, please visit <u>http://www.Dymola.com/compiler</u> where the latest links to downloading the compilers are available. Needed add-ons during installation etc. are also specified here. Note that you need administrator rights to install the compiler.

Also, note that to be able to use other solvers than Lsodar, Dassl, and Euler, you must also add support for  $C^{++}$  when installing the GCC compiler. Usually, you can select this as an add-on when installing GCC.

Current limitations with 32-bit and 64-bit GCC:

- Embedded server (DDE) is not supported.
- Support for external library resources is implemented, but requires that the resources support GCC, which is not always the case.
- FMUs must be exported with the code export option<sup>1</sup> enabled. **Note!** When migrating to Modelica Standard Library (MSL) version 4.0, MinGW gcc versions older than 5 are not guaranteed to work for source code export.
- For 32-bit simulation, parallelization (multi-core) is currently not supported for any of the following algorithms: RadauIIa, Esdirk23a, Esdirk34a, Esdirk45a, and Sdirk34hw.
- Compilation may run out of memory also for models that compile with Visual Studio. The situation is better for 64-bit GCC than for 32-bit GCC.

In general, 64-bit compilation is recommended for MinGW GCC. In addition to the limitations above, it tends to be more numerically robust.

#### WSL GCC compiler (Linux cross-compiler)

Dymola on window supports cross-compilation for Linux via the use of Windows Subsystem for Linux (WSL) GCC compiler. The default WSL setup is 64-bit only and Dymola adopts this limitation. Notes:

- WSL is usually not enabled on Windows, so you need to enable WSL on your computer and install needed software components.
- You must download and install a suitable Linux distribution, including a C compiler. We recommend Ubuntu 20 since it is the most tested version for Dymola. In particular, the integration algorithms RadauIIa, Esdirk23a, Esdirk34a, Esdirk45a, and Sdirk34hw have been confirmed to work with Ubuntu 20, but not with Ubuntu 18.

<sup>&</sup>lt;sup>1</sup> Having the code export options means having any of the license features **Dymola Binary Model Export** or the **Dymola Source Code Generation**.

• The WSL Linux environment can compile the generated model C code from Dymola in order to produce a Linux executable dymosim or a Linux FMU. (To generate Linux FMUs, you must use a specific flag as well.)

#### Dymola license server

For a Dymola license server on Windows, all files needed to set up and run a Dymola license server on Windows using FLEXnet, except the license file, are available in the Dymola distribution. (This includes also the license daemon, where Dymola presently supports FLEXnet Publisher version 11.16.2.1. This version is part of the Dymola distribution.)

As an alternative to FLEXnet, Dassault Systèmes License Server (DSLS) can be used. Dymola 2023 supports DSLS R2022x. Earlier DSLS versions cannot be used.

#### Linux

#### Supported Linux versions and compilers

Dymola 2023 runs on Red Hat Enterprise Linux 8.2, 64-bit, with gcc version 8.3.1, and compatible systems. (For more information about supported platforms, do the following:

- Go to https://doc.qt.io/
- Select the relevant version of Qt, for Dymola 2023 it is Qt 5.15
- Select Supported platforms)

Any later version of gcc is typically compatible. In addition to gcc, the model C code generated by Dymola can also be compiled by clang.

You can use a dialog to select compiler, set linker flags, and test the compiler by the **Verify Compiler** button, like in Windows. This is done by the command **Simulation > Setup**, in the **Compiler** tab.

You can however still change the compiler by changing the variable CC in /opt/dymola-<version>-x86-64/insert/dsbuild.sh. As an example, for a 64-bit Dymola 2023 application:

/opt/dymola-2023-x86\_64/insert/dsbuild.sh

Dymola 2023 is supported as a 64-bit application on Linux.

Notes

- 32-bit compilation for simulation might require explicit installation of 32-bit libc. E.g. on Ubuntu: sudo apt-get install g++-multilib libc6-dev-i386
- Dymola is built with Qt 5.15.0 and thereby inherits the system requirements from Qt. This means:
  - Since Qt 5.15 no longer supports embedding of the XCB libraries, these must now be present on the platform running Dymola. See the table in <a href="https://doc.qt.io/qt-5.15/linux-requirements.html">https://doc.qt.io/qt-5.15/linux-requirements.html</a> for the list of versions of the ones starting with "libxcb". Note that the development packages ("-dev") mentioned outside the table are not needed.
  - o The library libxcb-xinput.so.0 might require explicit installation.

• For FMU export/import to work, zip/unzip must be installed.

#### Note on libraries

"

• The library UserInteraction is not supported on Linux.

#### Dymola license server

For a Dymola license server on Linux, all files needed to set up and run a Dymola license server on Linux, except the license file, are available in the Dymola distribution. (This also includes the license daemon, where Dymola presently supports FLEXnet Publisher 11.16.2.1.)

As an alternative to FLEXnet, Dassault Systèmes License Server (DSLS) can be used. Dymola 2023 supports DSLS R2022x. Earlier DSLS versions cannot be used.